



2282-REAR LOAD
(2) #4 DROP BOXES

TYPICAL INSTALLATION:
(See Installation Instructions for more detail)

